

# Easy to Install

## Step 1



Measure length and position bracket.

## Step 2



Attach the bracket to the wall (Please install 2 screws here) .

## Step 3



Connection rod according to the window length.

## Step 4



Hanging the curtain on the rod.

## Step 5



Put the rod on the brackets, Pull out the 7/8-inch tube and screw the ends.

## Step 6



Tighten the screws to hold the rod