

MEDICINE CABINET INSTALLATION GUIDE

1. BEFORE STARTING

- Read all steps carefully before installation.
- Verify all parts are included.
- Work on a clean, carpeted or cardboard-protected surface.
- Hand-tighten all screws first; fully tighten only after full assembly.

2. WARNING

- Keep children and pets away during assembly.
- Do not let children climb on the unit.
- Avoid sharp objects and corrosive chemicals.
- Lift as a team; do NOT drag or push.
- Use power tools carefully to avoid stripping screws.

3. PARTS LIST

- A: M4×40mm Screws (11 pcs)
- C: M6×30mm Rubber Plug Screws (11 pcs)
- D: 12mm Screw Washers (8 pcs)
- E: Power Cord Plug (1 pc)
- F: 9×9mm Rubber Mats (2 pcs)
- Glass Shelf: 399×82mm (1 pc)

4. ADDITIONAL TOOLS REQUIRED

- Drill & drill bits
- Screwdriver
- Level
- Tape measure
- Wall stud finder
- Drywall saw (for recessed installation)

5. ROUGH WALL OPENING & WIRE HIDING

- Create a wall groove to route the power cord INSIDE the wall for clean, hidden wiring.
- Align wall openings with predrilled holes on the cabinet's back mounting bars.
- This ensures NO exposed wires and professional appearance.

6. SURFACE INSTALLATION

1. Mark 4 mounting holes on the wall matching the cabinet's back mounting bars.
2. Drill holes and insert anchors if needed.
3. Mount the cabinet firmly to the wall.
4. Route power cord through the wall groove to hide completely.

7. HARDWIRING INSTALLATION (OPTIONAL, HIDDEN CABLES)

- Turn off circuit breaker BEFORE wiring.
- Connect power cord wires to household junction box wires (match colors).
- Secure with wire nuts; push all wires inside the junction box.
- Mount cabinet to cover junction box — FULLY HIDDEN WIRING.
- This eliminates exposed cords and cheap appearance.

8. PREVENT DOOR FROM HITTING & DAMAGING WALL

- Install cabinet with minimum 0.8 inch (2 cm) clearance from side wall.
- Ensure door swings freely without touching drywall.
- Use wallfriendly rubber bumpers (included) on cabinet edges if needed.
- This prevents wall damage and scratches.

9. EASY DRYWALL INSTALLATION & PERFECT FIT

- Measure cabinet cutout dimensions first.
- Cut drywall opening 1–2 mm larger than cabinet for easy, smooth fit.
- Do not cut too small — this avoids forcing and cracking drywall.
- Secure into studs when possible for stability.

10. FINAL INSTALLATION CHECK

- Cabinet is firmly mounted.
- Wires are fully hidden (no exposed cables).
- Door opens/closes without hitting wall.
- All screws are tight.
- Glass shelf is securely placed.