

Installation instructions

Step 1.



Raise the side panel

Step 2.



Raise the rear panel

Step 3.



Raise the front panel

Step 4.



Embedded connection bar

Step 5.



Purchase 2 or more,
repeat steps 1-4

Overlay the box and
fasten the left and
right locks



Step 6.



Close the top cover

Step 7.



Install the wheels, complete!