












Installation & Assembly





Sideboard



PARTS LIST


A 	B 	C 	D 	E 
Top Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC	Bottom Panel 1 PC	Partition Panel 1 PC
F 	G 	H 	I 	J 
Shelf 2 PCS	Left Door 2 PCS	Right Door 2 PCS	Left Back Panel 1 PC	Right Back Panel 1 PC
K 	L 			
Cover 2 PCS	Support Leg 1 PC			

HARDWARE LIST

#1		#2		#3	 7*38mm	#4		#5	
	Handle 4 PCS		Double Magnet 4 PCS		Tapping Bolt 2 PCS (Extra 1)		Cam Bolt 10 PCS (Extra 1)		Cam Lock 10 PCS (Extra 1)
#6	 8*30mm	#7		#8	 6*3*15mm	#9	 6*3*15mm	#10	 8*3*12mm
	Wood Dowel 12 PCS (Extra 1)		Shelf Holder 8 PCS (Extra 1)		Round Head Screw 8 PCS (Extra 1)		Long Screw 8 PCS (Extra 1)		Short Screw 32 PCS (Extra 1)
#11		#12	 M2	#13	 M4	#14		#15	
	Binding Post 2 SETS (Extra 1)		Small Allen Wrench 1 PC		Allen Wrench 1 PC		Cam Sticker 10 PCS (Extra 1)		Safety Strap Kit 1 SET

ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.




Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Step 1. Attach double magnets (part #2) to panels (parts A & D) using round head screws (part #8) and phillips head screwdriver.


Insert cam bolts (part #4) into pre-drilled holes of panels (parts A, B & C) using phillips head screwdriver.

Note: Do not over tighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.




#2		x 4
#4		x 10
#8		x 8

Step 2. Attach covers (part K) to back panels (parts I & J) using binding posts (part #11) and small allen wrench (part #12).





Step 3. Attach handles (part #1) to doors (parts G & H) using long screws (part #9) and phillips head screwdriver.



Step 4. Attach panels (parts B & C) to bottom panel (part D) using cam locks (part #5), wood dowels (part #6) and phillips head screwdriver. Attach partition panel (part E) to bottom panel (part D) using tapping bolts (part #3), wood dowels (part #6) and allen wrench (part #13).

Note: Cam locks must rotate a full 180°. See pictured insert.





#3		x 2
#5		x 4
#6		x 6
#13		x 1

Step 5. Attach top panel (part A) to assembled unit (parts B, C & E) using cam locks (part #5), wood dowels (part #6) and phillips head screwdriver.


Attach support leg (part L) to bottom panel (part D).

Note: Cam locks must rotate a full 180°. See pictured insert.




#5		x 6
#6		x 6


Step 6. Attach back panels (parts I & J) to assembled unit (parts A, B, C, D & E) using short screws (part #10) and phillips head screwdriver.



Step 7. Carefully turn unit upright. Attach doors (parts G & H) by placing pin hinge (pre-installed in door) in the pre-drilled hole of bottom panel (part D). Then depress the top spring-loaded pin hinge so it can be placed in the pre-drilled hole of top panel (part A).
NOTE: Be sure top and bottom pin hinges are fully extended to secure doors in place.




Step 8. Place shelf holders (part #7) into desired position and slide adjustable shelves (part F) into place.




Step 9. Using cam stickers (part #14) cover cam locks (part #5).

NOTE: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.

Important: Safety strap kit (part #15) must be installed to prevent tipping damage and/or injury.




#15	A	B	C	D	E
					
Safety Strap Kit 1 SET	Wall Anchor 1 PC	Bracket 2 PCS	8*3*15mm Short Screw 1 PC	8*4*35mm Long Screw 1 PC	Safety Wall Strap 1 PC

SAFETY WALL STRAP INSTALLATION

Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) and safety wall strap (E) through bracket (B) and attach to top panel (part A) using phillips head screwdriver.
2. Drill a 11/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in top panel (part A) where bracket (B) is attached. Tap wall anchor (A) into the hole.
3. Insert long screw (D) and safety wall strap (E) through bracket (B) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- For use with televisions weighing 50lbs(23kg) or less. Use with heavier televisions may result in instability causing tip-over resulting in death or serious injury.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!