

1. Screw thumb nut approx. 1" down on to S-cluster nipple.
2. Place shade w/hole onto S-cluster nipple and seat to thumb nut.
3. Screw finial onto S-cluster nipple and tighten.
4. Place light bulbs into sockets, plug into wall outlet and enjoy.

