

INSTALLATION INSTRUCTIONS

■ PRODUCT



1 Product Parts



2 Lay out the four sides of the screen door in their corresponding positions, with the mesh folded and retracted (the black bar is the bottom, and the white bar is the top).



3 The suspension wheel is pushed into the top beam, and the top beam is connected to the connecting pins.



4 The protruding part at the bottom is inserted into the grooves of the mesh and connected to the pins, and the other end is also inserted into the pins.

5 Splicing complete.



6 The screws were tightened at each of the four corners.

Tip

Finally, there are two ways to connect it to the door:

1. You can choose to use adhesive tape for connection.
2. You can choose to use our screw accessories (long screws) and drill holes yourself for connection.