


# ASSEMBLY INSTRUCTIONS



## TOOLS REQUIRED



Allen Wrench  
(Included)



Phillips  
Screwdriver  
(Not Included)



**3 - People  
Recommended**

## ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



## **CHECK BEFORE STARTING**

### **Are you missing anything?**

Double-check all parts, hardware and accessories listed are all accounted for.

### **Check out our Quick Tips!**

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

### **Should we send any replacements?**

Are there any irregularities or flaws in the parts? We can send replacements!

### **Prep Time!**

Please review the assembly instructions and all diagrams prior to assembling.

# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



## Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



## Suitable Location

Assembling near the area of the intended location is highly recommended.



## Sufficient Space

Make sure you have enough space to move around during the assembly.



## Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



## Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

# ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

**IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.**











# EASTERN KING SIZE BED



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.









## PARTS

- |   |  |  |  |  |
|---|--|--|--|--|
| <b>#1</b> 1pc<br><br>Headboard                                     | <b>#2</b> 2pcs<br><br>Headboard Leg<br>L&R                            | <b>#3</b> 1pc<br><br>Footboard  | <b>#4</b> 2pcs<br><br>Side Rail                                | <b>#5</b> 2pcs<br><br>Platform Rail |
| <b>#6</b> 2pcs<br><br>Bed Slat with Marking<br>-1951 x 45 x 18mm | <b>#7</b> 4pcs<br><br>Bed Slat without Marking<br>-1951 x 45 x 18mm | <b>#8</b> 1pc<br><br>Platform Rail<br>Support<br>-1796 x 45 x 18mm | <b>#9</b> 10pcs<br><br>Bed Slat Support<br>-225 x 30 x 30mm |  |
| <b>#10</b> 6pcs<br><br>Concealed Panel<br>-2040 x 295 x 9mm      |  |  |  |  |






















## HARDWARE

### HARDWARE INSIDE HEADBOARD

- |  |   |  |   |  |   |
|--|---|--|---|--|---|
| <b>#A</b> 1pc<br><br>Allen Key M4 | <b>#B</b> 4pcs<br><br>Bolt 1/4" x 1-3/8" | <b>#C</b> 4pcs<br><br>Lock washer | <b>#D</b> 4pcs<br><br>Flat washer | <b>#E</b> 8pcs<br><br>CSK m4 x 32mm | <b>#F</b> 1pc<br><br>Adaptor |
|--|---|--|---|--|---|

### HARDWARE INSIDE SIDE RAIL

- |   |  |   |   |  |
|---|--|---|---|--|
| <b>#G</b> 12pcs<br><br>CSK m4 x 32mm | <b>#H</b> 10pcs<br><br>Bolt 1/4" x 2" | <b>#I</b> 30pcs<br><br>Pan Head Screw<br>m3.5 x 20mm | <b>#J</b> 1pc<br><br>Allen Key M4 | <b>#K</b> 1pc<br><br>Allen Key M5 |
|---|--|---|---|--|


Carton	Designation	Part		Hardware
	<b>King Size Bed HB</b>	#1		 #A x 1pc  #B x 4pcs  #C x 4pcs
		#2	 X 2	 #D x 4pcs  #E x 8pcs  #F x 1pc
	<b>King Size Bed FB</b>	#3		
	<b>E.King Size Bed Rails</b>	#4	 X 2	 #G x 12pcs  #H x 10pcs
		#5	 X 2	 #I x 30pcs  #J x 1pc
		#6	 X 2	 #K x 1pc
		#7	 X 4	
		#8		
		#9	 X 10	
		#10	 X 6	

# ASSEMBLY INSTRUCTIONS


1

Align Headboard Leg(#2) to Headboard(#1), then secure by using JCBC (#B), Spring Washer (#C) and Flat Washer (#D) tighten with Allen Key(#A). Also scure Headboard with CSK screw(#E) and tighten with Scew Driver(NOT PROVIDED)

- Part #1 x1pc
- Part #2 x2pcs
- Hardware #B x4pcs
- Hardware #C x4pcs
- Hardware #D x4pcs
- Hardware #E x8pcs



2




**CAUTION !!!**  
PLEASE  
CONNECT THE  
LED TERMINAL  
SOCKET  
AFTER FIT IN THE  
HOOK PART  
AS SHOWN.

PLEASE REMOVE MASKING TAPE  
BEFORE CONNECT

Align side rails (#4) & (#5) to the bolts of the headboard Leg (#2) and footboard (#3). Fully tighten the bolts.


- Part #3 x1pc
- Part #4 x2pcs
- Part #5 x2pcs
- Part #8 x1pc
- Hardware #G x2pcs



# ASSEMBLY INSTRUCTIONS


## 3

- Part #6 x2pcs
- Part #7 x3pcs
- Part #9 x10pcs
- Hardware #H x10pcs



## 4


- Hardware #G x10pcs




# ASSEMBLY INSTRUCTIONS

5

- Part #10 x6pcs
- Hardware #F x1pc
- Hardware #1 x30pcs



This is how the concealed panel (#10) look like on the bed from a high view.




Marking Line

Attach adaptor (#C).





Back View

To Active



Switch on Button



- 1) Please refer to steps (#5) on how to align and place concealed panels(#10) correctly.
- 2) Secure concealed panels (#10) to bed slats by using screws (#1).

## ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

### Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

### Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

