

## K304C/BLK Kitchen faucet



### Installation guide

1. Hand screw-in the hoses to the bottom of the faucet.



2. Screw in the large brass piece to the bottom of the faucet and put the rubber washer over the brass piece at the bottom of the faucet.



3. Then slip the hoses and faucet into the hole in the vanity top. From underneath the vanity top, slip the flat rubber washer and brass nut over the hoses and onto the threaded brass piece. Turn the nut finger tight so faucet is secure against the vanity top, and then install the ends of the hoses to the hot and cold water valves inside the vanity.

