


Assembly Instruction



1. Take the Base (A) carefully out of the carton, and place it on flat surface, make sure that the parts will not be damaged.

2. Take out sponge pads (B) from hardware bag, and put them on eight corners of the frame.

3. Take the Top (C) out of the honey comb box, and put them on each frame.

Hardware and tool included: sponge pads.

To clean, wipe with soft dry cloth .