

5/8" BAY WINDOW DRAPERY ROD INSTALLATION INSTRUCTIONS

Care Instructions: Clean with a soft cloth. Do not use abrasive cleaning agents, solvents or polishes.

SET INCLUDES:

(A) X14
(B) X14
(C) X3
(D) X2
(E) X2
(F) X1
 Extends 36-72"
(G) X2
 Extends 18-36"

YOU WILL NEED:

1/4" dia.

1

Before installation, measure windows to determine appropriate drapery rod length.

2

Beginning with the center window, measure approx. 6 inches from the wall corner and use bracket (C) as a guide to mark holes for mounting screws (A).

3

Drill pilot holes into wall with 1/4" drill bit (not included). Insert wall anchors (B) and attach bracket (C) using mounting screws (A). Wall anchors may not be necessary if drilling into studs.

4

Repeat steps 2-3 for additional brackets (C). Use level if necessary. Note: Center bracket may not be needed for all applications.

5 CENTER ROD

Extend telescoping rod (F) slightly. Place drapery panels (not included) on the rod. Screw corner connectors (E) to each end of the rod.

6 CENTER ROD

Extend rod to desired length. Hang rod on brackets (C).