

ASSEMBLY INSTRUCTION

1. Place the headboard & the footboard in front of each other such that they are placed at a distance to accommodate the side rail to fit in.
2. Place the side rail on one side of the headboard & footboard.
3. Align the fitting of the head board to the fitting on the side rails.
4. Slide the hook bracket no.2 of the side rail into the hook bracket no.1 of the headboard from the top down wards to fix the hooks together.
5. To fix the fitting completely, tighten the screws into the two empty screws slots.
6. Fix the other side rail to the headboard & foot board in the similar way.
7. Place the frame of the mattress frame with mid rail into the mattress slot from the top. Now your bed is ready for use.

