

The Queen Size Metal Platform Bed Frame assembly is designed to take approximately 30 minutes and involves a systematic process of connecting the frame components.

Step-by-Step Assembly Instructions

Step 1- Unpack & Organize: Lay all components on a soft surface (like a rug) to prevent scratching. Match numbered parts with the Instruction Manual.

Step 2 - Headboard & Footboard: Attach the vertical iron-art supports to the main headboard and footboard panels using the provided bolts. Do not fully tighten them yet.

Step 3- Side Rails: Connect the side rails to the headboard and footboard. Use the designated bolts and nuts, ensuring the hooks are properly seated.

Step 4 - Center Support: Install the central support beam and its legs. These provide the core stability for the 900 lb weight capacity.

Step 5 - Metal Slats: Insert one end of a slat into the side rail hole, then the other. Press down firmly until it clicks into the "insert design". Attach the silent buckle (mute sponge) to prevent noise

Step 6 - Final Secure: Tighten all bolts using the included Allen key only after all parts are aligned.