


Assembly Instruction

———— UK-CBN239A-140L ————



General Guidelines

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.


Notes

- The product is intended for indoor use only. The product must be assembled and used in accordance with the provisions of the manual. Personal injury and/or damage to product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The seller does not assume any responsibility or liability with respect to any injury/damage caused by incorrect assembly or improper use.
- Avoid long-term exposure to humid environments to prevent mildew.
- Keep the product away from fire sources and high temperatures. Do not expose the product to direct sunlight.
- Do not place any hot objects on the surface of the product.
- If there are any defective or missing parts after unpacking, please cease assembly immediately and contact us.
- Please assemble the item on a spacious surface and do not place the unwrapped product directly on the ground to avoid product damage.
- Please do not stand or sit on the wooden boards.
- Please wear gloves during the assembly and/or disassembly process to avoid scratches from any sharp edges.
- Please match the corresponding part and fitting based on the part number in the manual.
- If the part does not match with the fitting, please check the piece as specified in this manual.
- During assembly, first loosely align all screws with the corresponding pre-drilled holes and then tighten the screws one by one.
- Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity.
- If you accidentally spill water or another liquid on the surface, immediately wipe clean with a dry towel.
- Please keep the product away from sharp, pointed objects and corrosive substances to prevent product damage.
- Please place this item on level, solid ground during use.


Warnings

- During assembly, keep all small parts out of the reach of children. It may be fatal if swallowed or inhaled.
- Children should not climb or play on the product in order to avoid tipping over the furniture and causing serious injury.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (film, plastic bags, foam, etc.) away from babies and children.
- Keep sharp objects and corrosive items away from the product to avoid any damage or injury.
- Do not shake or move violently during use to avoid tipping over the product.


Parts List (EN)




Parts List (EN)




It takes two people to work together to assemble the product.



Recommended to use a screwdriver to assemble the product














Do not use a hammer, it might damage the board.




The use of an electric wrench is not recommended. If used, please set the torque to the minimum.

① 1PC	② 1PC	③ 1PC	④ 1PC
⑤ 1PC	⑥ 1PC	⑦ 1PC	⑧ 1PC
⑨ 1PC	⑩ 1PC	⑪ 2PCS	⑫ 2PCS
⑬ 1PC	⑭ 1PC		


Parts List (EN)

No. A Quantity: 24+2 Pcs Cam Lock Dowel 8*28mm 	No. B Quantity: 24+2 Pcs Cam $\phi 15$ 	No. C Quantity: 16+2 Pcs Sticker $\phi 20$ 	No. D Quantity: 14+1 Pcs Dowel 8*30mm 
No. E Quantity: 4 Pcs Large curved door hinge 	No. F Quantity: 1 Sets 	No. G Quantity: 36+3 Pcs Screw M3.5*12mm 	No. H Quantity: 12+1 Pcs Screw M6*40mm 
No. I Quantity: 2 Pcs Cover hole 	No. J Quantity: 2 Sets Cabinet Door Rebounder 	No. K Quantity: 4+1 Pcs Screw M6*25mm 	No. L Quantity: 1 Pc Allen Key 4# 
No. M Quantity: 8 Pcs Expansion bolt M8*40mm 	No. N Quantity: 8 Pcs Screw M5*60mm 	No. O Quantity: 1 Pc Screwdriver 	

Instructions For Fastening CAM-BOLT and CAM-LOCK




CAM-BOLT




CAM-LOCK


Tools Required




INSERTING AND TIGHTENING CAM-BOLT



Place Cam-bolt on pre-drilled hole and screw in vertically




Shoulder is flushed (on the same level) with the panel.



Shoulder is above the panel.

Place Cam-bolt on the designated pre-drilled holes on the panel. Use a Phillips Screwdriver to screw-in Cam-bolt vertically until shoulder is flushed (on the same level) with panel.


INSERTING CAM-LOCK



Insert Cam-lock with arrow align to Cam-bolt head **CORRECT** **WRONG**


Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.

TIGHTENING CAM-LOCK




Use a Flat-head Screwdriver to turn Camlock clockwise so it locks onto the head of the Cam-bolt. Turn until it is snug (about 3/4ths of a turn) -- over-tightening could damage Cam-lock or/and Cam-bolt.


STEP 1



Note: Please distinguish the numbering of the screws.







Note: Push the accessory into the card slot to complete the installation.





Note: The hardware can be rotated to adjust the fit here. If the cabinet body has been assembled and the door panel is recessed or protruding, it can be adjusted by turning the hardware.

	G×4PCS
	J1×2PCS
	J2×2PCS



STEP 2







	A×2PCS
	B×2PCS
	D×2PCS



STEP 3









Please note during installation that the holes on these two panels need to be aligned and should be installed facing upwards.






	A×2PCS
	B×2PCS
	D×2PCS

STEP 4








	A×8PCS
	B×8PCS
	D×2PCS

STEP 5




	D×1PCS
	H×6PCS
	L×1PCS



STEP 6






	A×2PCS
	B×2PCS
	D×2PCS




STEP 7









Please note during installation that the holes on these two panels need to be aligned and should be installed facing upwards.



	A×2PCS
	B×2PCS
	D×2PCS





STEP 8






	A×8PCS
	B×8PCS
	D×2PCS

STEP 9



	D×1PCS
	H×6PCS
	L×1PCS

STEP 10



	C×16PCS
	I×2PCS
	K×4PCS
	L×1PCS

STEP 11




Hinge Adjustment (Door Alignment)

Scan the QR code to watch the hinge adjustment video.



If you notice any of the issues below, follow these steps:

Front screw: Adjusts the gap between the door and the side panel (left/right).

Rear screw: Adjusts the door position front-to-back (in/out)





12-A. When the door panel is higher than the side panel.




If the gap is too big between side panel and door or the door is over the edge of side panel, loosen the back screw as shown, then move in the door with hinge and tighten the back screw as shown when the gap is just well.

12-B. When the door panel is lower than the side panel, an indentation occurs.




If the gap is too small between side panel and door or the door sank in side panel, loose the back screw as shown, then move out the door with hinge and tighten the back screw as shown when the gap is just well.


12-C




If the gap between the two doors is too small, follow the diagram.




12-D




If the gap between the two doors is too large, follow the diagram.




12-E




If the gap between the door and the side panel is too small, loose the front screw as shown.






12-F



If the gap between the door and the side panel is too large, tighten the front screw as shown.






12-G. When door is leaning





Turn "front screw" to the left can make the top of the door tilted outward.

12-H. When door is leaning




Turn "front screw" to the left can make the bottom of the door tilted outward.

12-I. When the door is higher on top





then lock screws.




If the doors are not in the same level, loosen the back screws on wing, then adjust the door up and down, tighten the screws when both doors are in same level. Screw front two screws on wing when all are in place.

STEP 13





Before installing the door panels, please study and read the following steps. For possible problems, we have given some suggestions to solve the problems you encounter.





x4

Please note that you need to distinguish the front and back when installing the metal plate.



	E×4PCS
	G×16PCS
	J3×2PCS
	J4×2PCS

STEP 14



x4



Tighten the screws when both doors are in same level.
Screw front two screws on wing when all are in place





NOTE:

If there is a large gap between the doors or between the door and the side panel after installation, please refer to page 17 or page 19 for the adjustment video and tutorial.



G×8PCS




STEP 15



When tightening the support rod, slightly lift the two door panels and align the two guide holes before tightening.

 F1	F×1PC
 G	G×4PCS





STEP 16



When tightening the support rod, slightly lift the two door panels and align the two guide holes before tightening.

	F×1PC
	G×4PCS

STEP 17



Note:
First, secure the "12" accessories, then hang the cabinet, and the assembly is completed.

	M×8PCS
	N×8PCS