


ASSEMBLY INSTRUCTIONS FOR #48917 (M92)



IMPORTANT

TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION

CAREFULLY UNPACK AND IDENTIFY ALL PARTS BEFORE ASSEMBLY. BULBS ARE NOT INCLUDED

- 1.) Each M92 comes with 4 different length down rods with couplings attached to allow the fixture to hang at the desired length. (If the hardware is at the desired length, continue to step 4.)
- 2.) In order to change or add to the down rod, unscrew rod from the valve, pull the fixture wires through the canopy, and attach down rod(s) using the coupling(s).
 - 3.) Once desired length is reached, feed fixture wires back up through canopy and screw down rod back into valve.
 - 4.) Attach crossbar to j-box using customer supplied screws.
 - 5.) Raise up hardware to crossbar, wire as per local electrical codes, and secure with canopy screws.
 - 6.) Place shade, steel supporting ring, then cork washer onto shade fitter and secure with wire ring.



"A Commitment to Excellence in Lighting and Service"

CALL OUR CUSTOMER SERVICE DEPARTMENT AT 1-800-222-4899

MONDAY - FRIDAY 8:00 a.m. - 6:00 p.m. ET

visit us on the web at www.meyda.com