

1" DRAPERY ROD INSTALLATION INSTRUCTIONS - 18-36" ROD SET

Care Instructions: Clean with a soft cloth. Do not use abrasive cleaning agents, solvents or polishes.

SET INCLUDES:

(A) (B) (C) (D) (E) (F)

X4 X4 X2 X1 X1 X1

Extends 18-36"

Note: Finial (D w/ smaller post) fits to the smaller diam. rod - Finial (E w/ larger post) fits to the larger diam. rod.

YOU WILL NEED:

1/4" dia.

1

Extends 18-36"

Before installation, measure windows to determine appropriate drapery rod length.

2

Use bracket (C) as a guide to mark location for mounting screws (A).

3

Drywall

Drill pilot holes into wall with 1/4" drill bit (not included). Insert wall anchors (B) and attach bracket (C) using mounting screws (A). Wall anchors may not be necessary if drilling into studs.

4

Repeat steps 2-3 for additional bracket. Use level if necessary.

5

Extend telescoping rod (E) slightly.

6

Place drapery panels (not included) onto drapery rod and insert finials (D & E) into ends of rod. Extend rod to desired length and hang rod on brackets. Snap rod into brackets (C) to secure in place.