

Screen Set

ASSEMBLY Instructions

Parts





Screen Panel x 3



Step 1

Attach **Stand Foot** to **Stand Riser - Long** using 4 nuts and 4 bolts. Tighten using pliers and Allen Key. Repeat for second **Stand Foot** and second **Stand Riser - Long.**



Step 2

Attach *Screen Panel* to first assembled *Stand Riser Bar – Long* using 2 nuts and 2 bolts. Make sure the panel is placed in the channel with narrow end side holes facing up (as shown). Repeat with second Assembled Riser Bar. Hand tighten only.



Step 3

Slide second *Screen Panel* into channel of assembled stand. Ensure the panel is placed in the channel with the narrow end of side holes facing up. **Note** – panel may fit tightly and may require a rubber mallet to nudge the panel into place. Hand tighten using 4 nuts and 4 bolts (bottom holes connected to stand only).



Step 4

Attach **Stand Riser Bar – Short** to last **Screen Panel** as shown using 2 nuts and 2 bolts. Repeat with second Stand Riser Bar – Short. Hand tighten only.





Panel side view before assembly

Step 5

Slide last *Screen Panel* with *Stand Riser Bar – Short* onto *Screen Panel – Middle Piece.* Note – panel may fit tightly and may require a rubber mallet to nudge the panel into place. Install remaining nuts and bolts.



Step 6

Tighten remaining nuts and bolts using pliers and allen key.

NOTES - Multiple assembled sets can be bolted together - A rubber mallet or hammer may be required to nudge panels into place.

TOOLS REQUIRED - Pliers, Allen Key