

Assembly Instructions For The Poly Classic Rocker

Tools Needed

7/16" Wrench
7/16" Socket
Square Drive Bit
Screwgun

Parts List

Back Assembly: 1
Seat Assembly: 1
Right Arm & Leg Assembly: 1
Left Arm & Leg Assembly: 1
Rockers: 2

Hardware

1/4"x3-1/2" Carriage Bolts (4)
1/4"x2-3/4" Carriage Bolts (2)
1/4"x2" Carriage Bolts (4)
1/4" Flange Nuts (10)
2-1/2" Screws (4)

- Step 1** Lay out and identify all parts and pieces.
- Step 2** Place the seat assembly on edge with the front slat facing down. Place the arm and leg assemblies on the proper sides. (with the curved part of the arm on the outside.) Line up the holes in the legs with the holes in the side of seat assembly. Insert a 3-1/2" carriage bolt in each hole & put flange nuts on and semi tighten. (Do not fully tighten until the back is attached.)
- Step 3** Lay the back assembly down between the arms. Line up the holes in the arms to the holes in the side of the back assembly and fasten with the 2-3/4" carriage bolts & flange nuts.
Now take the 2-1/2" screws and fasten the bottom of the back assembly to the seat assembly, at the predrilled holes.
- Step 4** Attach the rockers to the leg assemblies by lining up the holes in the rockers with the holes in the bottom of the legs. Fasten with the 2" carriage bolts & flange nuts, using the socket to tighten the nuts.
Now make sure all the nuts are tightened, and enjoy your rocker.