

安装流程

Installation Procedure

图一
Figure 1

椅子打开靠墙平衡放好，找到孔位做记号。
The chairs are balanced against the wall and marked with holes



图二
Figure 2

普通电钻（勿用冲击钻），对准记号钻孔，如瓷砖较硬，建议使用玻璃钻头引孔，然后再用普通钻头打深孔（40MM深）
Common Electric Drill (do not use charging drill, aim at mark drill hole, if ceramic tile is hard, use glass drill to guide hole, then use common drill to drill deep hole (40MM deep))



6MM的钻头(普通瓷砖两种任选一种)
6MM Bit (one of two common ceramic tile options)

图三
Figure 3

对准孔位安装胶塞
Fix The rubber stopper to the hole position



6MM玻璃钻头（超硬瓷砖选用此钻头）
6MM GLASS BIT (this bit is used for super hard ceramic tile)

图四
Figure 4

椅子靠墙对准孔位加固螺丝
SEAT WALL-TO-WALL BUTTRESS SCREWS

