

EASY INSTALLATION

- a. Turn on the supply stop valves for 30s to 1 min to flush the debris in the supply lines. Turn off the supply stop valves again.
- b. Connect the Hot Labeled Hose to the Hot Water Supply. Cold Labeled Hose to the Cold Water Supply. Tighten the Nuts with wrench. DO NOT OVER TIGHTEN
- c. Connect the third Hose to the Connector. Tighten the Nuts with wrench. DO NOT OVER TIGHTEN.
- d. Connect the Extension-Hose to the shank of the Spout from under the deck. Tighten the Nuts with wrench. DO NOT OVER TIGHTEN.
- e. Connect the Shower Hose with the Extension-Hose from under the deck. Tighten the Nuts with wrench. DO NOT OVER TIGHTEN.
- f. Turn on the supply stop valves and check connections for leaks. Retighten if necessary. but DO NOT OVER TIGHTEN.

