



Step 1: Line up 1:1 and 2:2 (this will be the bottom shelf). Place bottom shelf upside down on top of legs and line up holes.

Step 2: Place washers on bolts and insert into underside of bottom board and leg holes (for 1 and 2). Screw them down (don't overly tighten).

***There are 3 holes, but only 2 are necessary for stability. In some cases, not all 3 will fit perfectly due to the nature of the reclaimed wood.*



Step 3: Line up 3:3 and 4:4 - holes will be in the bottom support pieces of the top panel and the sides of the legs.

***If it makes it easier to reach, you can place the top piece upside down on the floor and fit the legs into the side spaces to assemble.*

Step 4: Place washers on bolts and insert into holes. Screw them in (don't overly tighten).

***As in step 2, if you are not able to place all 3 bolts, 2 per side is sufficient.*

