

Easy and convenient installation

Wall hanging installation method



01 Install the expansion screw into the wall



02 Hang the screws into the dovetail hook

Paste, install, and use



01 Wipe the wall clean with a dry cloth



02 Apply a sufficient amount of nail free adhesive evenly on the back



03 Evenly press the flat surface to expel air



04 Wait for 72 hours for complete solidification before hanging the mirror

Special reminder:

Worn, old, powdery, wallpaper, and other walls are not suitable for use