

UPHOLSTERED PANEL HEADBOARD A S S E M B L Y
I N S T R U C T I O N S

1. Line up holes on Leg A with holes on side A of the headboard. Insert 1 screw in each of the 3 holes. Please note the stem of the leg should be to the back of the headboard and the leg should be facing forward.
2. Now repeat the above process with Leg B.