

Installation instructions



1 Take the product out of the carton and place it sideways.



2 Unfold to both sides to full.



3 Press the back baffle down to clasp.



4 Pull out the door panel to the door frame and lock the two buckles at the bottom of the door frame.



5 Close the door.



6 The installation is complete.