

Instructions for Assembly of Daybed

(for ADB, JDB, SDB, CHDB, CLDB, PPDB, TRDB)

TOOLS NEEDED: SCREWDRIVER; HAMMER (Holes are pre-drilled)

STEP 1. Place the metal flat-springs on two chairs or stools as shown below.

STEP 2. Assemble the metal flat-springs parts using the drawing which is inside the other plastic bag attached to the flat-springs. Adjust brackets to make flat-springs as short as possible.

STEP 3. Attach wicker side panels loosely to both ends of the flat-springs using the short bolts in this bag. DO NOT TIGHTEN NUTS FULLY. Use the upper holes (12 3/8' setting).

STEP 4. Attach the back panel to the side panel by tapping the longer bolts through both sections of wicker. Tighten Nuts.

STEP 5. Tighten nuts on side panels and flat-springs parts, add mattress and use.

IF YOU NEED ASSISTANCE, CALL 1 800 597 7061

