

Assembly Instructions for the Headboard

Step 1:

Lay panels 14 and 15, 7 and 8, and 5 and 6 flat on the ground. Connect them using wooden dowels (C) inserted into the side holes. Then, following the diagram, secure the joints with metal plates (F) using screws (D) at four points near the seams, and reinforce with metal plates (E) at two points. Tighten the screws.

Step 2:

Insert the threaded end of bolts (A) into the six pre-drilled holes on panels 8 and 7. Place wooden dowels (C) into the four designated holes on the same panels. Then, stand the assembled 7 and 8 panels upright and insert the bolts and dowels into the corresponding holes on panels 5 and 6. Align locking nuts (B) with the bolts and rotate them using a screwdriver to secure the connection.

Insert wooden dowels (C) to connect panels 4 and 6, as well as panels 3 and 5. Ensure that the pre-drilled holes for locking nuts on panels 4 and 5 face upward, as shown in the diagram.

Step 3:

Insert bolts (A) into the six designated holes on panel 2 and place wooden dowels (C) into the six corresponding holes. Then, connect it to the assembly from Step 2, securing the bolts using locking nuts (B) in the same manner as before.

Step 4:

Insert bolts (A) and wooden dowels (C) into the designated holes on panel 1. Connect it to the structure following the same method used in Step 3, securing the bolts with locking nuts (B).

Step 5:

Attach padding pieces (K) to the indicated positions on the assembled structure.

Step 6:

Insert bolts (A) and wooden dowels (C) into the designated holes on panels 9 and 10. Using locking nuts (B), secure the connections following the diagram, then set the assembled structure aside.

Step 7:

Place switch (G) into the pre-cut rectangular slot and secure it using screws (D).

Step 8:

Stand the assembled unit from Step 5 upright. Insert bolts (A) and wooden dowels (C) into the pre-drilled holes at the top of panels 7 and 8. Then, attach the assembly from Step 6 by aligning the holes and ensuring that all groove openings are on the same side for easier installation of the next steps.

Step 9:

Insert the back panel into the corresponding slots according to the numbered positions.

Step 10:

Insert bolts (A) and wooden dowels (C) into the designated holes on the assembled 14 and 15 panels. Then, flip the assembly and position it on top, aligning it with the holes in the lower structure. Secure it with locking nuts (B).

Step 11:

Thread the control wires from the switch through the two circular holes near the socket, running from top to bottom. Following the diagram, connect the control wires of the light strip to the control panel, then plug in the power cord to complete the setup.

Thank you for choosing our headboard! To ensure stability and durability, multiple bolts and wooden dowels are required for assembly. As a finishing touch, use stickers (H) to cover the screw holes for a cleaner look.

If you have any questions along the way, please don't hesitate to ask—we're here to help!