



Insert the threaded ends along the foot (#2) into the holes along the bottom of the night stand (#1), turn right to tighten.