



Swing-Arm Sconce Instruction

Safety Warning

Turn OFF power at the breaker panel and verify the wires are not live before beginning.

Installation Steps

• Step 1: Attach the Mounting Plate

Attach the round mounting plate (1) to the wall junction box with the two #8-32 screws supplied. The two threaded posts must face outward and sit level.

• Step 2: Wire the Fixture

1. Bring the fixture body close to the plate and join the leads with the supplied wire connectors:
 - Black (hot) → black
 - White (neutral) → white
 - Green/bare (ground) → green/bare or the ground screw on the plate
2. Twist connectors clockwise and tuck the splices neatly inside the junction box.

• Step 3: Mount the Fixture Arm

Slide the backplate of the arm assembly over the threaded studs until it rests flat against the wall.

• Step 4: Secure the Fixture

Thread the decorative cap nuts / set screws onto the exposed studs and hand-tighten to lock the fixture arm in place. Do not overtighten.

• Step 5: Position the Glass Shade

Carefully lower the ribbed glass shade over the socket, making sure it is centered and seated evenly.

• Step 6: Tighten the Retaining Collar

Thread the metal retaining collar onto the socket to clamp the shade securely. Snug by hand; excess force may crack the glass.

• Step 7: Install the Bulb

Screw one E26 LED bulb, 25 W max into the socket and tighten until snug.

Final Check

Restore power at the breaker panel and test the sconce. The bulb should illuminate evenly and the shade should be stable with no wobble.