

# Assembly Guideline

## Step 1



Take the components out of the compressed bag, gently fluff it and allow 24-72 hours for the bed to inflate fully.

## Step 2



Insert the foam into dog bed cover. Please note that both sides of the sponge can be used as the sleep contact surface. We recommend using it with the memory foam side facing up.

## Step 3



Close the zipper securely.  
Note: Put one finger under the zipper while closing the zipper in case of jam.

## Step 4



Congratulations, assembly is complete! The dog bed will return fully shape after 24-72 hours.