




Installation & Assembly




IT IS RECOMMENDED
TO USE POWER TOOLS




60MIN




EN_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.




EN_QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.













EN_CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.




EN_Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.










EN_Turn cam lock clockwise to tighten.


NO.	PARTS	QTY	SPARE
1		x1	
2		x1	
3		x1	
4		x2	
5		x1	
6		x1	
7		x1	
8		x1	
9		x2	
10		x2	

[illegible]




 A x6 Ø6x35mm +1(spare)	 B x6 Ø15x10mm +1(spare)	 C x10 Ø6x30mm +1(spare)	 D x14 Ø4x35mm +1(spare)	 E x24 Ø3.5x12mm +2(spare)	 F x8 Ø6x25mm
 G x4	 H-1  H-2	 I x4	 J-1  J x8 Ø3x16mm +1(spare) J-2	 K-1  K x2 Ø4x14mm K-2	 L x2 Ø6x30mm
 M x8 +4(spare)	 N x1	 O x4 Ø6x35mm			

D x8




01




C x4




02



D x4






03



04

N x1



O x4



05

F x8


N x1




C x6




06



A x6




07



B x6




08





G x4







09






J x8

M x8




D x2



K x2



L x2



K-1

First fix the anti-rewind screw in the reserved hole of the product.

K-2



(1)x2



then, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.

(2)x2

WALL


+
drilling hole
Ø6x30mm



(3)x2

Then use a tape drill to make holes in the wall that are suitable for the product screws.


WALL



Then, put the expansion bolt into the hole


(4)x2

WALL



Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.

(5)x2



WALL

