

## ASSEMBLY INSTRUCTIONS:

1. Carefully unpack and place all lamp parts on a flat surface.
2. Unscrew the socket ring (C) from the socket assembly (A).
3. Attach the shade (B) onto the socket assembly (A), reattach socket ring (C), turning clockwise until tight.
4. Install the bulb, then insert the polarized plug into a wall outlet and enjoy.
5. To clean, use a soft dry cloth only. Never use chemical or abrasive cleaners.

**Use a 23W CFL Type bulb or 100W (Maximum) Incandescent A Type bulb.**

※ PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.

※ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

