

1. Remove all the screws from the pole first, then align the pole with the holes on the tripod. Fix the tripod with the screws, with the square straight rod above and the circular straight rod Below



2. Fix the bracket to the wall with screws



3、 Place the wooden board on top