

installation instructions:

SIGNATURE URETHANE DENTIL TRIM

SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear safety goggles.

Follow fixture, power tools, and paint manufacturers' instructions and users manuals.

Use common sense and follow good construction practices.

Braces are not load-bearing, decorative use only.

TOOL & MATERIAL CHECKLIST

- | | |
|--|---|
| <input type="checkbox"/> Miter saw & box | <input type="checkbox"/> Sandpaper |
| <input type="checkbox"/> Hammer or nail gun | <input type="checkbox"/> 100% acrylic paint |
| <input type="checkbox"/> Nails | <input type="checkbox"/> Tape measure |
| <input type="checkbox"/> PL Premium adhesive | <input type="checkbox"/> Utility knife |
| <input type="checkbox"/> Acrylic caulk | <input type="checkbox"/> Safety glasses |
| <input type="checkbox"/> Caulk gun | |

IMPORTANT INFO

- Clean installation surface and brace of all dirt and dust with a clean cloth or dry sponge.
- It is highly recommended that you paint/finish our braces before installation.
- Once installed, you can apply any necessary touch-up paint/finish.
- You can use standard woodworking tools to cut or drill.
- Hot-dipped galvanized or stainless steel nails/screws are best for Signature Urethane trim.
- Fill fastener holes in with Signature Urethane acrylic caulk.
- Glue joints and miters together with PL Premium.
- Use 100% acrylic paint before installing, finish with final coat to cover caulk holes.

INSTALL INSTRUCTIONS:

Mitering Corners

1. Place moulding in the miter box with the wall side against the side of the miter box opposite you and the ceiling touching side against the bottom of the box.
2. Cut miters and butt joins prior to installation.

Moulding Installation

1. Apply a continuous 1/2" bead of PL Premium adhesive along the top and back of moulding lengths. Press moulding into place. (Diagram A)
2. Secure the moulding in place with finishing nails (Diagram B)
3. Apply caulk in remaining gaps and smooth with finger.
4. Lightly sand any touch-up areas and paint as needed.

EXAMPLE DIAGRAM:

DIAGRAM A



DIAGRAM B



EKENA
MILLWORK

Industry leading manufacturer of urethane, Signature Urethane, wood, rustic, and metal millwork

We Can Help. Call (866) 607-0453

www.ekenamillwork.com