
ASSEMBLY INSTRUCTION:

***VERY IMPORTANT**

PLEASE READ THOROUGHLY. MAKE SURE YOU PROPERLY ALIGN POLES BEFORE SCREWING THEM TOGETHER TO AVOID DAMAGING CONNECTION THREADS. NOT ADHERING TO THIS PROCEDURE MAY VOID YOUR WARRANTY!

- 1. CAREFULLY UNPACK AND IDENTIFY ALL PARTS.
- 2. PLACE SHADE [B] OVER SOCKET AND SECURE IT WITH SOCKET RING [C].
- 3. INSTALL BULB [D] INTO SOCKET.
- 4. PLUG THE POWER CORD INTO OUTLET AND TURN ON SWITCH.



IMPORTANT SAFETY INSTRUCTION

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

- PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.
- **** SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

