


# ASSEMBLY INSTRUCTIONS

---



---

Description : 24 IN STOOL

Printed in Vietnam

## BEFORE ASSEMBLY

Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability. All parts were checked prior to packaging to insure quality. Prior to beginning assembly, however, make sure all parts and hardware are included and free of obvious defect. If a part is missing or defective, please contact the store where purchased.

### IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.







### ASSEMBLY TOOLS REQUIRED

NOT INCLUDED



## PART LIST








When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have the following parts:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
A	Chair back	1		B	Seat Frame	1	
C	Front Stretcher	1		D	Side stretcher	2	
E	Front Leg (L-R)	2		F	Chair seat	1	

Printed in Vietnam

## HARDWARE LIST


When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have all of the following hardware:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
1	Short bolt (M6x40mm)	3		2	Medium bolt (M6x60mm)	4	
3	Long bolt (M6x80mm)	4		4	Flat washer (Φ6.5x Φ19mm)	11	
5	Screw (M4x35mm)	10		6	Allen Key (4x80mm)	1	
7	Lock washer (Φ6.5xΦ11mm)	11					

## STEP 1


Attach seat frame (B) to the back (A) by using bolts (3) and (1) and washers (4) and (7). Tighten with allen key (6).

Note: DO NOT tighten any of the bolts, until the chair is assembled, then put on a flat level surface to make sure the chair is level and then tighten the bolts.



## STEP 2

Attach Front Legs (E) to the seat frame. Use bolts (2), washers (4) and (7). Tighten with allen key (6). Place side stretchers (D) and front stretcher (C) between front and back legs. Attach stretchers with the screws (4) as shown below. Tighten with a screwdriver.



## STEP 3

Attach the seat (F) to top of the seat frame (from Step 2) by using screws (5). Tighten with a screw driver.

