

Assembly Instruction (Queen/Full Headboard)

1).When attach a Full size bed frame to this Headboard, please connect the bedframe to the metal plates B on the headboard legs with your own hardware .



2).When you use Queen size bed frame, you need to remove the metal plates B first from the headboard legs (Screw off bolts A by the provided Allen Key). Then connect your bed frame directly to the headboard legs using the bolts A.

3). Periodically check to ensure all connectors (bolts and screws etc.)are tight.

4). Prohibit jumping on the bed.

5). Please check the maximum load capacity of your bed frame and do not exceed that weight.

(Bed Frame is not included. Hardware for connecting Full size bed frame is not provided.)

	Allen Key 1PC
	Bolt A 6pcs (Already on the legs for assembly metal plates)

