

Installation Notes

This product is equipped with expansion tube screws, traceless hanging stickers, traceless nails, and cement nails.

Expansion pipe screws are suitable for cement walls, white lime walls, ceramic tile walls, and wooden walls.

Seamless hanging stickers are suitable for smooth tile walls, glass walls and smooth metal walls.

Traceless nails and cement nails are suitable for cement walls, white lime walls, and wooden walls.

How to install expansion pipe screws



Step 1: Confirm where the product will be hung on the wall.

Step 2: Drill a small hole with an electric drill.

Step 3: Place the expansion tube into the small hole.

Step 4: Screw the screw into the expansion tube

Step 5: Leave about 1cm between the screws and the wall.

Step 6: Align the product with the screws and hang.

How to install incognito stickers



Step 1: Confirm where the product will be hung on the wall.

Step 2: Wipe down the wall where the product will be hung.

Step 3: Peel off the protective film on the back of the traceless sticker

Step 4: Place the traceless hanging sticker where you want to hang it, and then remove the air inside.

Step 5: Hang the product.

Traceless nail installation method



Step 1: Confirm where the product will be hung on the wall.

Step 2: Place non-marking nails where you want to hang the product.

Step 3: Drive all 3 small nails on the non-marking nails into the wall.

Step 4: Hang the product.

How to install cement nails



Step 1: Confirm where the product will be hung on the wall.

Step 2: Place cement nails where you want to hang the product

Step 3: Drive cement nails into the wall

Step 4: Leave a distance of 1cm between the cement nails and the wall

Step 5: Hang the product