

# Cubicle Mounted U-Channel Installation Instructions

## Parts



**1)** Use allen wrench provided to loosen top screw and open bracket wide. Standard brackets fit panels from 1.5" to 2.75" thick. Large brackets fit panels from 2.75" to 3.75" thick



**2)** Measure a hands with in from the edge of the panels, set bracket, and close tight with hand pressure. Tighten top screw with allen wrench.



**3)** Slide screen into upper channel (make sure the set screws are backed out enough to allow screen to slide all the way down) and tighten set screws.

