

Parts List:	
Part No.	Quantity
A	x4
B	x4
C	x1

Step 1:

- Place template on a flat surface and lay organizer on top of the template.
- Mark the location of the organizer's 4 mounting holes onto the template.

Step 3:

- Remove the template sheet.
- Insert Wall Anchors (A) and tap flush.

Step 2:

ATTENTION:  
Drill bit size 3/16" (5mm).

- Tape the template sheet to the wall in the desired location and confirm it is centered and level.
- Drill 3/16" (5mm) holes in the center of each marking on the template.

Note: For solid walls, drill hole to a minimum depth of 1" (or 25.4mm).

Step 4:

- Using a Phillips head screwdriver, screw Mounting Screws (B) through the mounting holes of the Organizer (C) into the Wall Anchors (A).

Note: The two topmost screw holes are accessed through earring holes.