



Clean the wall to ensure that the wall is dry and clean



Select the installation position, keep horizontal and draw a dot mark with the screw as the center,

Do the same on the other side



Loosen the screws holding the base with a delivery wrench



Use a 6MM drill bit to drill holes at the marked locations



Punch the expansion pipe into the hole to make it parallel to the wall or sink in



Tighten the base with a Phillips screwdriver



When installed, the base is almost seamless to the wall



Install the product on the base and tighten the screws to complete the installation and use

You can drill holes in the wood and screw the screws directly into it, without electric drill and expansion tube

