

How to Install

1. Determine where the clock will be installed.
2. Secure the nail with a hammer (not included).
3. Align the nail with the wall clock.
4. Complete the installation easily and conveniently.