DRAWER BASE CABINETRY ASSEMBLY INSTUCTIONS


Aershin Cabinets

Prepare a protection layer, a screwdriver

STEP 1: Pick up the frame
STEP 2: Joint side panel with frame using METAL BRACKET & SCREW 4*15
STEP 3: Joint another side panel with frame using METAL BRACKET & SCREW 4*15
STEP 4: insert bottom panel
STEP 5: Put on PLASTIC BRACKET for drawer using SCREW 4*14 Flat hat
STEP 6: Attach back panel using SCREW 3.5*40
Joint back panel with side panel (back direction) using CLEAT & SCREW 3.5*12
Joint back panel with side panel (bottom direction): using METAL BRACKET & SCREW 4*15
STEP 7: Joint toe kich with side panel using CLEAT & SCREW 3.5*12
STEP 8: Joint back panel with side panel (Upper direction) using METAL BRACKET & SCREW 4*15
Attach slides using SCREW 4*14 Flat hat
STEP 9: Assemble the drawer
STEP 9: Install the GLIDE RUNNER onto the drawer bottom panel using SCREW 4*14
STEP 10: Install the Drawer onto the Glides and fit the glide hook into the hole of the drawer back.
STEP 11: Put on the BUMPER
STEP 12: Fix door on the frame and adjust the cover-space

PARTS LIST		
NO	DESCRIPTION	QTY
A	SIDE PANEL	2
B	BACK PANEL	1
C	BOTTOM PANEL	1
D	FACE FRAME	1
E	TOE KICK	1
F	DRAWER FRONTS	2/3
G	DRAWER BOTTOM PANEL	2/3
H	DRAWER SIDE PANEL	4/6
I	DRAWER BACK PANEL	2/3



HARDWARE LIST			
NO	DESCRIPTION	QTY	PICTURE
1	SCREW 3.5*12 Round hat	32 / 36	
2	SCREW 3.5*40	2 / 3 / 4	
3	CLEAT	8 / 9	
4	BUMPER	8 / 12	
5	METAL BRACKET	8	
6	SCREW 4*15 for BRACKET	32	
7	GLIDE RUNNER	4 / 6	
8	PLASTIC BRACKET for drawer	4 / 6	
9	SCREW 4*14 Flat hat	24 / 36	

unitedcabinetry

STEP 9: Joint drawer side panel with drawer front
Insert the drawer bottom panel and joint
Assemble the drawer back panel with side panel



STEP 10:



STEP 10:



STEP 11:



STEP 12:

