


ASSEMBLY INSTRUCTION

PLEASE READ BEFORE ASSEMBLING!


Tip #1: Make sure you've taken all the pieces and hardware out of its packaging before discarding the box.

Tip #2: Using page 2 and/or page 3 of instruction manual make sure all pieces and hardware are accounted for.

Tip #3: Read manual before assembling, it helps!









PARTS IDENTIFICATION




(1)	1pc	(9)	1pc
(2)	2pcs	(10)	1pc
(3)	2pcs	(11)	1pc
(4)	1pc	(12)	1pc
(5)	1pc	(13)	1pc
(6)	1pc	(14)	1pc
(7)	1pc	(15)	2pcs
(8)	1pc		


HARDWARE IDENTIFICATION

A		L29	26pcs
B		Ø15	26pcs
C		Ø8×25	22pcs
D		Ø4×30	4pcs
E		Ø4×10	1set
F		48×48×14	1pc
G		L20	4pcs
H		Ø12	4pcs
I		Ø20	8pcs
J		Z1016	20pcs
K		197×5×1	1pc
L		Ø4×25	1pc
M		Ø5×40	1pc
N		Ø8×40	1pc
Q		12×12×1	2pcs
O		Ø16	4pcs
P		Glue: For securing please apply to wood dowel first before inserting into panel	1pc

ASSEMBLY INSTRUCTION




STEP 1




STEP 2

STEP 3




ASSEMBLY INSTRUCTION




STEP 4

STEP 5




ASSEMBLY INSTRUCTION


STEP 6



STEP 7



STEP 8




ANTI-TIPPING STRAP INSTRUCTION


HARDWARE (INCLUDED) :



DRYWALL ANCHOR $\Phi 8 \times 40$ X 1PC



METAL BRACKETS $12 \times 12 \times 1$ X 2PCS



DRYWALL SCREW $\Phi 5 \times 40$ X 1PC




STRAP $197 \times 5 \times 1$ X 1PC



FLATHEAD SCREW $\Phi 4 \times 25$ X 1PC

TOOLS NEEDED (NOT INCLUDED) :




DRILL & DRILL BIT



LIGHT HAMMER


Note: Hardware included only compatible with standard drywalls.

STEP 1




1. Find spot on wall 1" below top of item.
2. Using a drill bit slightly thinner than anchor, drill hole into drywall.

STEP 2




1. Use a light hammer to tap anchor into hole.
2. Anchor should fit snugly. If hole is too small, drill again to increase hole size. Do not force anchor into wall.

STEP 3



1. Insert drywall screw into metal bracket and into drywall anchor.
2. Insert flathead screw into second metal bracket and into back of item along top edge.

STEP 4



1. Insert strap thru bracket attached to wall, then thru bracket on item, and into head of strap.
 2. pull lightly til strap stops.
- Assembly is complete.