





Model : Z0199002L Z0199002W

As this item contains many parts, please read the installation instruction carefully before installation and complete the installation with the cooperation of your partner. Please use tools properly and carefully. If you have any questions about the product and installation, please contact us.

zooged@yeah.net

Our professional after-sales team will serve you online all day.

Before You Start



Read through each step carefully and follow the proper order



Separate and count all your parts and hardware



Give yourself enough room for the assembly process



Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer




Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.

Helpful Hints


PEOPLE NEEDED FOR ASSEMBLY: 1-2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with an **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.
- Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.




Part List


Not actual size




CAM LOCK
spare:2




CAM BOLT
spare:2




WOODEN DOWEL
spare:2




SCREW
spare:3




CRASH PAD
spare:1




BOLT
spare:1




BOLT




PLASTIC WEDGE
spare:1



FOOTPADS




HANDLE





Tipping restraint hardware kit(inside plastic bag)

Cam Lock Fastening System




Insert the cam bolt into the hole first, then insert the cam lock and lock it.

Tools Required





(Not included) 😊










(Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.)

Board Identification



Not actual size



STEP1



Before you install this screw, please
make sure the screw size is M6*25mm




STEP2






C

X 4




A

X 4









Insert the cam bolt into the hole first, then insert the cam lock and lock it.








Proper orientation of CAM LOCK


STEP3








STEP4




STEP5



STEP6






Insert the cam bolt into the hole first, then insert the cam lock and lock it.










Proper orientation of CAM LOCK

STEP7




STEP8






X 3

Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

STEP9








Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

STEP10




STEP11



STEP12

WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.




Tools required: Phillips screwdriver, Power Drill, 2/5" Drill Bit and Rubber Mallet.

1	2	3
		

WARNING

This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

Do Not allow children to climb on unit.
Put heavy items on lower shelves or drawers



IMPORTANT NOTE

Young children (and/or pets) can be seriously injured by tipping furniture units.

You must install the provided anti-tip kit hardware solution, as instructed to prevent the furniture unit (s) from tipping over-which could possibly lead to injuries or damage.

The provided anti-tip kit hardware solution is intended only as an additional safety measure a deterrent; it is not a substitute for proper adult supervision

The provided anti-tip kit hardware solution is not an earthquake restraint. If you wish to add the extra security of earthquake restraints they must be purchased and installed separately