


ASSEMBLY INSTRUCTIONS



Kitchen Cabinet



NOTE TO CUSTOMERS:



- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten, as this may damage the product.
- Please ensure you retain all the product packaging until the item completely assembled.
- Please periodically check all fittings and re-tighten as necessary.
- Please never allow any liquids to remain on your furniture as absorption can cause the wood to warp or finish to de-laminate.
- It is recommended that this item should be assembled by two adults.

To insert a cam lock: (Please read below instructions before assembling)





1. Insert cam screw into hole as shown in diagram A .

Diagram B




Make sure not to insert the cam screw:
Too deep as shown in figure B as this will cause the
cam screw to be misaligned and unable to
interlock properly.


Diagram C



Also avoid inserting the cam screw too close to the
surface of the hole as shown in figure C, as this will
cause the cam lock to be too loose, and not interlock
properly.




2. Connect the panels together.



ARROW SIGN



3. When inserting the cam lock make sure the arrow
of the cam lock faces the cam screw.





















4. To tighten the cam lock turn the cam lock clockwise
90-180 degree or until the arrow is facing opposite
the place cam lock was inserted.

**NOTE: DO NOT USE AN AUTOMATIC
SCREWDRIVER TO TIGHTEN CAM LOCKS.**





Note:

- Read these instructions carefully before assembling.
- Tools required : Phillips screwdriver, flat screwdriver.
- Find a clean, smooth area on which to work , such as a carpet, in order to avoid scratching the wood surfaces.
- Wait to dispose of the packing material until assembly is complete and all parts and hardware are accounted for.
- Two or more people might be required for assembly.

Part List

A1. Quantity of 1  Front Apron	A2. Quantity of 1  Back Apron	A3. Quantity of 1  Bottom Panel	A4. Quantity of 1  Divider
A5. Quantity of 1  Top Connect Panel	A6. Quantity of 1  Side Panel(left)	A7. Quantity of 1  Side Panel(right)	A8. Quantity of 1  Top Panel
A9. Quantity of 2  Back Panel	A10. Quantity of 2  Shelf	A11. Quantity of 1  Large Door	A12. Quantity of 1  Center Back Panel
A13. (L, R) Quantity of 4  Drawer Side Panel	A14. Quantity of 2  Drawer Back Panel	A15. Quantity of 2  Drawer Bottom Panel	A16. Quantity of 2  Drawer Front Panel
A17. Quantity of 1  Small Door	A18. Quantity of 1  Middle Connect Panel		


Hardware List

B1. Quantity of 16  Wood Dowel	B2. Quantity of 24  Camlock	B3. Quantity of 22  Screw	B4. Quantity of 8  Shelf Support
B5. Quantity of 8  Screw	B6. Quantity of 2  Magnet	B7. Quantity of 4  Knob with Bolt	B8. Quantity of 16  Screw

STEP 1


Assembly Instructions

B1		2pcs
B2		4sets



Assemble Front Apron A1 and Back Apron A2 to Bottom Panel A3 using Camlocks B2 and Wood Dowels B1.


STEP 2



B1		3pcs
B2		4sets
B6		1set

- 1), Attach Magnet B6 to Middle Connect Panel A18 by included screws.
- 2), Assemble Top Connect Panel A5 and Middle Connect Panel A18 to Divider A4 using Camlocks B2 and Wood Dowels B1.
- 3), Assemble Dividers A4 to Bottom Panel A4 using Camlocks B2 and Wood Dowels B1.


STEP 3



B1		8pcs
B2		10sets


- 1), Assemble Side Panel A7 to Top Connect Panel A5 , Middle Connect Panel A18 ,Bottom Panel A3 , Back Apron A2 and Front Apron A1 using Camlocks B2 and Wood Dowels B1.
- 2), Assemble Side Panel A6 to Bottom Panel A3 , Back Apron A2 and Front Apron A1 using Camlocks B2 and Wood Dowels B1.

STEP 4




- 1), Attach Magnet B6 to the bottom of Top Panel A8 by included screws.
- 2), Assemble Top Panel to Side Panels A6/A7 and Divider A4 using Camlocks B2 and Wood Dowels B1.

STEP 5



1. First place Back Panels A9, then place Center Back Panel A12 as shown above.
2. Tighten Back Panels A9 and Center Back Panel A12 to unit using Screws B3.


STEP 6



B4		4pcs
B5		4pcs
B7	 	1set

- 1), Attach Knob B7 to Door A11 with included bolt. Then assemble Door Panel A11 to Left Side Panel A6 using screws B5.
- 2), Insert Shelf Supports B4 into holes on Left Side Panel A6 and Divider A4, then put Shelf A10 onto Shelf Supports B4.


STEP 7



B4		4pcs
----	---	------

Insert Shelf Supports B4 into holes on Right Side Panel A7 and Divider A4, then put Shelf A10 onto Shelf Supports B4.

STEP 8




B8		16pcs
B7		2set

X2

- 1). Insert Drawer Bottom Panel A15 into the groove on Drawer Front Panel A16.
- 2). Attach Drawer Side Panels A13(L&R) to Drawer Front Panel A16 using Screws B8, please ensure the grooves on the Drawer Side Panels A13(L&R) face inside of drawer.
- 3). Attach Drawer Back Panel A14 to Drawer Side Panel A13(L&R) using Screws B8.
- 4). Attach Knob B7 to Drawer Front Panel A16 using included Bolt B7.


STEP 9



Insert Drawers as shown above.








STEP 10

B5		4pcs
B7	 	1set



Attach Knob B7 to Door A17 by included bolt. Then assemble Door Panel A17 to Right Side Panel A7 using screws B5.

APPENDIX: Dimension of Hardwares in this AI.

B1.  Wood Dowel	B2.   Cam-bolt Cam-nut	
B3&B6.  Round Head Screw	B5.  Flat Head Screw	B7.  Bolt for Knob
B8.  Flat Head Screw		