



# **WG** *Wood Products*

## **2018 - Product Assembly & Installation Instructions** **For ALL IN THE WALL MODELS**

| Models Covered:                                                                                                                                                                                                                                                    | Tools Needed:                                                                                                                                                            |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Newberry, Reeves, Franklin, Concord, Cove Niches, Blair, Bishop, Lawrence, Curio cabinets, Johnstown, Franklins Baldwin, Napa Valley, Plantation, Elkhart Kensington, Belmont, Basehor, Bookcase, Addison, Archer, Regan, Grand, Blackwell, Belleview, WC-4 Series | Drill or Cordless Screwdriver with Phillips bit, 3/16" drill bit, Hammer, Scissors, tape measure and pencil, drywall saw, caulking gun (Optional), construction adhesive |

1. Determine if your model is a single cabinet or a two-piece cabinet. Two-piece cabinets will be 44" and taller and will have screws already in the bottom of one cabinet section which allows you to screw the cabinet back together. Two-piece cabinets will have the trim around three sides only. If you have a two-piece cabinet, screw the two sections back together before installation. Paint or stain the cabinet and door if desired. **See Image 1**

2. Screw on the Back Panels being careful to go straight so that your screws don't come out on the inside of the cabinet. Depending on model and finish this may already be done. **See Image 2**

3. Use a stud finder to locate the studs and mark them.

**You'll want your product to go between the studs whenever possible to avoid having to cut through one.**

**If you do need to cut through a stud, a reciprocating saw will do the job without damaging the wall on the opposite side.**

4. Measure the back side of the cabinet and lay out the marks on the wall at the height you desire.



# WG *Wood Products*

## 2018 - Product Assembly & Installation Instructions For ALL IN THE WALL MODELS

5. Once your opening has been marked out on the wall use a drill and drill a 3/8" hole in each corner of your marked opening. Insert a drywall saw into the first hole and cut to the next one. Continue in this manner until you have the entire opening cut out.
6. If you have insulation in the opening, you will need to cut that out or slice through it so that you can push it to the top, bottom or sides of the opening such that it will allow you to place the unit inside
7. Lay the cabinet on a flat surface upside down. Use liquid nails or similar construction adhesive and place a bead of it all the way around the back side of the unit's frame which overhangs the box. **See Image 3 & 4**
8. Place the cabinet in the opening and push firmly into place making sure again that the cabinet trim is flush all the way around. If desired you can place a thin bead of caulk around the trim to compensate for any unevenness in the wall surface. **Do Not** silicone, you cannot paint that to hide it. IF you use latex painters caulk you will be able to paint it.
9. If the cabinet has a door follow the instruction sheet for Blum Soft close concealed hinges to attach the door to the cabinet



# **WG** *Wood Products*

## **2018 - Product Assembly & Installation Instructions** **For ALL IN THE WALL MODELS**

**Image 1 attaching cabinet together**



**Image 2 Tack on Back Panel**



**Image 3 Apply Construction Adhesive Around the Edge of the Cabinet.**



**Image 4 Apply Construction Adhesive**



©2012 WG WOOD PRODUCTS, 213 FIELD END ST. SARASOTA, FL 34240

(913) 829-6000 [WGWOODPRODUCTS@COMCAST.NET](mailto:WGWOODPRODUCTS@COMCAST.NET)