

# ASSEMBLY INSTRUCTIONS

1. CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE AND LAY THEM UP AS PER THE SKETCH.
2. SCREW TUBE B INTO TUBE C, SCREW TUBE A INTO TUBE B, INSERT TUBE A INTO BASE, SECURE THE LAMP BODY AND BASE TOGETHER WITH WASHIER AND BUTTERFLY NUT, PULL EXTRA CORD OUT FROM THE BOTTOM OF BASE.
3. INSERT SHADE INTO THE CUP ON THE TUBE C, SECURE THE SHADE WITH SOCKET RING.
4. SCREW BULB INTO THE SOCKET, INSERT THE POWER PLUG INTO PLUG SEAT TO USE

**Recommended (1) maximum 60 WATT Type “A” Bulbs  
Or (1) maximum 13WATT CFL Bulbs (Bulbs not included)**

**SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

