



Master Garden Products

WHC-36 & WHC-36C Assembly & Installation Manual

Items Included: Cabinet Top, Cabinet Bottom w/ drawers, 4 pieces of hardwood (Teak), 12 2.5" Screws

Additional Items Needed: Power Drill, Measuring Tape, Pencil or Pen for marking, Eight 1.5" wood screws. You will also need at least one other person to help assemble/install.



Step One: Read Entire Directions Before Beginning! Decide where the cabinet is going to be installed.

Find Your Studs. Working with the lower section (Part B), measure where the studs are in relation to the edge of the cabinet. Make note of these. You will be using 2 pieces of Part C (teak hardwood) per cabinet section. Three 2.5" screws and two 1.5" screws per wood "bracket".

Step Two: Using the measurements you just took, mark both the front and the back of the cabinet where the studs & wood will be lined up.

Step Three: Using the 1.5" screws, affix the wood directly to the stud, approximately two inches from the top and bottom of the wood. Then, making sure the cabinet is aligned the way you want it, and you have room to use the power drill (**don't line it up so you would have to drill through the wine rack area**), you will use the 2.5" screws to screw through the back of the cabinet, and the wood, into the studs. Drill approximately 3 inches from top and bottom of the wood pieces, and then one about in the middle (about 7" from top or bottom)

Step Four: With another person helping you, set Part A on top of Part B. Go back to Step Three to secure Part A to the wall.

If you so choose, you can also purchase and install a wall mounting kit for cabinets/bookcases for extra safety, especially if you live in an Earthquake prone area. These kits are sold at many home improvement stores, as well as online.

