

1" DRAPERY ROD INSTALLATION INSTRUCTIONS - 72-144" ROD SET

Care Instructions: Clean with a soft cloth. Do not use abrasive cleaning agents, solvents or polishes.

SET INCLUDES:

(A) (B) (C) (D) (E) (F) (G)

X8 X8 X4 X1 X1 X1 X1

Note: Finial (D w/ smaller post) fits to the smaller diam. rod - Finial (E w/ larger post) fits to the larger diam. rod. Adaptor (F) is used with finial (D) to fit to second larger diam. rod.

YOU WILL NEED:

1/4" dia.

1

Extends 72-144"

Before installation, measure windows to determine appropriate drapery rod length.

2

Use bracket (C) as a guide to mark location for mounting screws (A).

3

Drywall

Drill pilot holes into wall with 1/4" drill bit (not included). Insert wall anchors (B) and attach bracket (C) using mounting screws (A). Wall anchors may not be necessary if drilling into studs.

4

Repeat steps 2-3 for additional brackets. Use level if necessary.

5

For 72-98"

Use 2 telescopic rod sections (1 larger diam. and 1 smaller diam.) Insert finial (D) into the smaller diam. rod.

For 98-144"

Use 3 telescopic rod sections. Extend the smaller diam. rod that is nestled in the larger diam. rod. Then insert the smaller diam. into the second larger diam. rod section. Attach adaptor (F) to finial (D) and insert into either of the larger diam. rods.

6

Place drapery panels (not included) onto drapery rod and insert finials (D) into ends of rod. Extend rod to desired length and hang rod on brackets. Snap rod into brackets (C) to secure in place.