



**STEP 1:** Measure the length and then cut panel and blank piece to suitable size

**STEP 2:** Use 3M double sided tape etc.



**STEP 3:** Pull protective layer off and stick blank piece on panels

**STEP 4:** Place the panels

