

Easy Installation

All Mounting Hardware Included

1 Mark the Position



Measure and mark the desired position on the wall.

2 Drill Holes



Use an 6mm (15/64") drill bit to drill holes at the marked positions.

3 Insert Wall Anchors



Insert the provided wall anchors into the drilled holes.

4 Install Mounting Bases



❌ Up: wrong orientation



Correct gasket installation



❌ Installed reversely

Align the mounting bases with the anchors and secure them to the wall using the provided screws.

5 Put Holder On Base



Put the holder on the installed mounting bases.

6 Tightening Little Screws



Use the Allen wrench to tighten the set screws on the bottom of each holder.

7 Interior View After Installation



Interior view after installation is complete.

Installation Complete



Enjoy your new towel rack!



Tips: Please make sure the mounting bases are installed in the correct direction.



Drill Bit
(6mm)



Wall Anchors
x4



Mounting Screws
x4



Allen Wrench
x1